

Lawrence Livermore National Laboratory

Nuclear Accident Dosimetry Exercises at CEA-Valduc



Andrew Wysong

Presented at the Nuclear Criticality Safety Program Technical Conference
at Oak Ridge National Laboratory, March 1, 2011

Lawrence Livermore National Laboratory, P.O. Box 808, L-198, Livermore, CA 94551-0808

This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344

Outline

Topics

- **2009 SILENE Nuclear Accident Dosimetry Exercise**
 - Preparation for Exercise
 - Exercise Setup Overview
 - Exercise Results
 - Lessons Learned

- **2010 CALIBAN Nuclear Accident Dosimetry Exercise**
 - Preparation for Exercise
 - Exercise Setup Overview
 - Preliminary Results

- **Future Work**



2009 NAD Exercise Overview


Participating Laboratories




LAWRENCE
LIVERMORE
NATIONAL
LABORATORY




2009 NAD Systems




LLNL



LANL



PNNL





SRS

SILENE Reactor

SILENE Reactor

- Uranyl-nitrate solution reactor
- Operates in three modes: **pulse**, free evolution, steady state
- Pulse mode initiated by rapid withdrawal of control rod
- Reaction stops due to bubbling of liquid and then liquid is quickly evacuated from reactor core
- Operated bare and with a lead shield



Lawrence Livermore National Laboratory



Exercise Setup

- **Three Pulses**
 - Pulse 1 – Lead Shield
 - Pulse 2 – No Shield, High Yield
 - Pulse 3 – No Shield, Low Yield
- **Phantom Arrangement**
 - Setup at 2 m, 4 m, and 6 m distances
 - Bibs contained dosimeters on front, side, or rear of phantom



Lawrence Livermore National Laboratory



Exercise Results - Neutron

US Laboratory Exercise Results

Neutron Dose (Rad)

Pulse	Shield	Distance (m)	Valduc	LLNL	Y-12	LANL	PNNL	SRS
1	Lead	2	690	791	800	650	634	546
		4	190	232	290	270	NR	NR
		6	110	109	160	NR	NR	NR
2	None	2	320	344	340	310	367	425
3	None	6	150	159	180	150	78	154

Exercise Results – Neutron

US Laboratory Exercise Results

Relative Neutron Results to Given Values

Pulse	Shield	Distance (m)	Valduc	LLNL	Y-12	LANL	PNNL	SRS
1	Lead	2	1	1.15	1.16	0.94	0.92	0.79
		4	1	1.22	1.53	1.42	NR	NR
		6	1	0.99	1.45	NR	NR	NR
2	None	2	1	1.08	1.06	0.97	1.15	1.33
3	None	6	1	1.06	1.2	1	0.52	1.03

According to ANSI/HPS N13.3, *Dosimetry for Criticality Accidents*, nuclear accident dosimetry systems should be able to provide sufficient data to calculate the dose within $\pm 25\%$. Results in green meet this performance criterion while results in red do not.

Exercise Results - Gamma

Integrated US Laboratory Exercise Results

Gamma Dose (Rad)

Pulse	Shield	Distance (m)	Valduc	LLNL	Y-12	LANL	PNNL	SRS
1	Lead	2	50	221	180	420	276	262
		4	30	46	80	160	NR	NR
		6	20	28	50	NR	NR	NR
2	None	2	380	432	330	420	467	494
3	None	6	210	172	160	180	187	295

Exercise Results - Gamma

Integrated US Laboratory Exercise Results

Relative Gamma Dose Relative to Given Values

Pulse	Shield	Distance (m)	Valduc	LLNL	Y-12	LANL	PNNL	SRS
1	Lead	2	1	4.42	3.6	8.4	5.52	5.24
		4	1	1.53	2.67	5.33	NR	NR
		6	1	1.4	2.5	NR	NR	NR
2	None	2	1	1.14	0.87	1.11	1.23	1.3
3	None	6	1	0.82	0.76	0.86	0.89	1.4

According to ANSI/HPS N13.3, *Dosimetry for Criticality Accidents*, nuclear accident dosimetry systems should be able to provide sufficient data to calculate the dose within $\pm 25\%$. Results in green meet this performance criterion while results in red do not.

Lessons Learned

- **Insufficient Operational Experience**
 - Instrumentation and personnel have changed resulting in personnel with no practical experience
 - Training of dosimetry personnel on their dosimetry system should be formalized and increased across complex
- **Detector Technology Has Advanced**
 - Nuclear accident dosimetry technology is substantially unchanged
 - Neutron activation analysis imposes time restraints on short lived isotopes
 - Difficulty in accounting for complex power history
 - Measurements require expert interpretation
 - NAD systems could take advantage of current technology or new technology to eliminate process steps and lessen reliance on experts
- **Gamma Dose TLD Needs Investigation**
 - Results from all laboratories (particularly pulse 1 – 2m) were far too high
 - Additional testing is necessary to resolve this anomaly



Lessons Learned

- **Throughput of Activated Foils is the Limiting Factor**
 - Counting irradiated samples must be done before activation of sample becomes too low and information is gone
 - To achieve good statistics these counts require time
 - Crosstalk of samples due to multiple teams added an additional complication
- **A Thorough and Reoccurring Testing Program is Needed**
 - Every participating laboratory expressed a strong desire for continued opportunities to test and refine their dosimetry system as well as train operations personnel to demonstrate regulatory compliance and competency
 - *ANSI/HPS N13.3 Nuclear Accident Dosimetry* is being rewritten with these participating labs taking the lead



2010 CALIBAN NAD Exercise

Participating Laboratories

- All 2009 Participants Returned
 - LLNL
 - LANL
 - PNNL
 - SRS
 - Y-12
- New Participant





- Many other organizations expressed interest but could not be accommodated until exercises are established with Godiva

CALIBAN Reactor


CALIBAN Reactor

- Unreflected HEU metal fast burst reactor (similar to SPR)
- Operated in pulse mode
- Pulse mode initiated by rapid insertion of control rods
- Solid core composition
 - 10 fuel discs & 4 control rods
 - 93.5% HEU metal alloyed with 10 wt% Mo




Preliminary Exercise Results

US Laboratory Exercise Results



Preliminary Exercise Results

US Laboratory Exercise Results



Lawrence Livermore National Laboratory

Note: PNNL and Y12 photon doses are estimated from published photon to neutron ratios. LLNL doses measured with ionization chambers.



Future NAD Exercises

- **2013 Godiva NAD Experiment at Nevada National Security Site (NNSS)**
 - Laboratory participants were limited by equipment and setup available at CEA-Valduc
 - LLNL is coupling the experience of the past two NAD exercises in France with operational experience at NNSS to develop a counting laboratory for upcoming NAD experiments using Godiva.
 - Godiva radiation field in DAF must be characterized to provide reference values
 - Counting Laboratory will feature all the proper safety equipment, workspace, hand tools, and utilities (i.e. power)
 - Counting Laboratory should provide a fume hood to allow processing of irradiated dosimetry elements (e.g. crushing, melting, burning sulfur)
 - Counting Laboratory should include moveable shielding to minimize crosstalk
 - Routine exercises should be provided in the future for training of dosimetry personnel
 - NNSA should consider hosting an OECD International Intercomparison Exercise

