


Nuclear Data Adjustment with SAMMY Based on Integral Experiments

Vladimir Sobes*
Luiz Leal
Goran Arbanas

*Nuclear Data and Criticality Safety Group
Reactor and Nuclear Systems Division
Oak Ridge National Laboratory*

**sobesv@ornl.gov*






SAMINT: A Code for Nuclear Data Adjustment with SAMMY Based on Integral Experiments

- Allow coupling of differential and integral data evaluation in a continuous-energy framework
- Update the parameters of a resolved resonance region evaluation directly based on integral benchmark experiments


Traditional SAMMY Evaluation

- Traditionally SAMMY has used differential experimental data ($\sigma(E_i)$ vs E_i) to adjust nuclear data parameters:
 - Resonance energies
 - Resonance widths
 - Number of prompt neutrons per fission
 - Etc...
- Integral experimental data, such as ICSBEP benchmarks, have remained only a tool for validation of completed nuclear data evaluations.



Integral Experiments to Aid Nuclear Data Evaluation

- SAMINT can be used to extract information from integral benchmarks to aid the nuclear data evaluation process.
- Near the end of the evaluation based on differential experimental data, integral data can be used to:
 - Resolve remaining ambiguity between differential data sets
 - Guide the evaluator to troublesome energy regions
 - Inform the evaluator of the most important nuclear data parameters to integral benchmark calculations
 - Improve the nuclear data covariance matrix evaluation



SAMMY



ENDF

SAMINT


Proper Uses

- SAMINT **is not intended** to bias the nuclear data towards fitting a certain set of integral experiments
- SAMINT should be used to **supplement** evaluation of differential experimental data
- Using the GLLS methodology ensures that the update nuclear data parameters respect the original fit of the differential data



Using SAMINT with SAMMY

Differential Experimental Data



SAMMY

$$d\sigma(E)/dP$$

SAMINT

$$dk/dP$$

$$dk/d\sigma(E)$$

CE TSUNAMI
MCNP-6

SAMMY

Updated P and δP

ENDF

P stands for all resonance parameters: E_λ , Γ_γ , Γ_n , Γ_f , etc.

Integral Experimental Data



SAMINT Today and Tomorrow

Current Capabilities

- Adjusting resolved resonance parameters and associated covariance
- Adjusting number of prompt neutrons per fission
- Calculating continuous energy cross sections and eta values (reactor physics) to satisfy integral benchmarks
- Works with both CE TSUNAMI and MCNP-6 k-eigenvalue sensitivities
- Iteration for non-linearity

Future Developments


- Near term:
 - Expansion to the unresolved resonance region
- Long term:
 - Expansion to high energy region
 - Adjustment of angular distribution data and associated covariance
 - Support for future TSUNAMI generalized sensitivity theory developments

Results and Analysis

- SAMINT used to improve resolved resonance region evaluation of ^{56}Fe which had previously given discrepant results.
- Four integral experiments from the ICSBEP were selected.
- Energy region of evaluation: 1e-5 eV to 2 MeV.
- 1190 resonance parameters varied:
 - Γ_{γ} : 450 keV – 2MeV
 - $\Gamma_{(n,n'),1}$ and $\Gamma_{(n,n'),2}$: 846 keV – 2MeV




⁵⁶Fe Results




- **C/E:** $\frac{\text{Computed Value}}{\text{Experimentally Measured Value}}$

Cross Section Changes: Finer Scale than Differential Experimental Data



Inelastic cross section of ^{56}Fe before ($\chi^2 = 73.3382$) and after ($\chi^2 = 73.6877$) the adjustment based on integral experimental data plotted on top of differential experimental data of Plompen, presented with one standard deviation error bars.


Cross Section Changes: Finer Scale than Differential Experimental Data



Inelastic cross section of ^{56}Fe before ($\chi^2 = 23.6023$) and after ($\chi^2 = 22.9036$) the adjustment based on integral experimental data plotted on top of differential experimental data of Perey, presented with one standard deviation error bars.

Summary

- SAMINT should be used to **supplement** evaluation of differential experimental data.
- SAMINT will also improve the nuclear data covariance matrix evaluation.
- Plans to extend the SAMINT methodology to the unresolved resonance region and the high energy region.



SAMMY



ENDF