

Thermal Epithermal experiments (TEX) Subcritical Experiment Results with PlutoniumAluminum Zero Power Physics Reactor (ZPPR) and Polyethylene

Presented at the Nuclear Criticality Safety Program (NCSP) Technical Program Review March 15-16, 2016 at Sandia National Laboratories, Albuquerque, NM

Catherine Percher, Doug McAvoy, Donald Kavanagh,
Todd Matz, Gary Slavik, and David Heinrichs
Lawrence Livermore National Laboratory




IER 184: Thermal/Epithermal experiments (TEX)


- TEX Motivation
 - July 2011 at Sandia National Laboratories, Albuquerque, NM
 - Representatives from US, UK, and France in nuclear criticality safety, critical experiments, and nuclear data
 - Intermediate spectrum experiments needed
 - Limited Data (2.1% of ICSBEP Benchmarks)
 - Consensus prioritization of nuclear data needs (in order):
 - ²³⁹Pu, ²⁴⁰Pu, ²³⁸U, ²³⁵U, Temperature variations, Water density variations, Steel, Lead (reflection), Hafnium, Tantalum, Tungsten, Nickel, Molybdenum, Chromium, Manganese, Copper, Vanadium, Titanium, and Concrete (reflection, characterization, and water content)
- CED-2 (FY14) showed Final Design of TEX experiments using Zero Power Physics Reactor (ZPPR) Pu-Al plates moderated by polyethylene with tantalum diluents
- FY2015: First subcritical experiment to test heat dispersal plates and investigate personnel dose concerns



Final Design Plutonium Baseline Experiments


- Five experiments, covering thermal, intermediate and fast fission energy regimes
- PANN plates arranged in approximately 12" x 12" layers (6 plates by 4 plates)








Plutonium Baseline Experiments






Baseline Experiment Characteristics

| Thickness of PE Plates (in) | Mass (ka | Number of Pu Layers | Number of ZPPR Plates | Stack Height (cm) | Thermal Fission Fraction (<0.625 eV) | Intermediate Fission Fraction (0.625 eV- 100 KeV) | Fast Fission Fraction (>100 KeV) |
|-----------------------------------|-------------|---------------------------|-----------------------------|-------------------------|---|---|---|
| 0 (no PE) | 49.8 | 21 | 504 | 12.5 | 0.09 | 0.17 | 0.74 |
| 1/16 | 40.3 | 17 | 408 | 13.5 | 0.14 | 0.38 | 0.49 |
| 3/16 | 28.5 | 12 | 288 | 12.0 | 0.27 | 0.43 | 0.30 |
| 7/16 | 19.0 | 8 | 192 | 15.9 | 0.48 | 0.33 | 0.19 |
| 1 | 14.2 | 6 | 144 | 20.5 | 0.67 | 0.21 | 0.12 |






Tantalum Diluent Experiments






Tantalum Experiment Characteristics

| Thickness of PE Plates (in) | Critical Mass (kg ²³⁹ Pu) | Number of Pu Layers | Number of ZPPR Plates | Stack Height (cm) | Thermal Fission Fraction (<0.625 eV) | Intermediate Fission Fraction (0.625 eV- 100 KeV) | Fast Fission Fraction (>100 KeV) |
|-----------------------------------|---|---------------------------|-----------------------------|-------------------------|---|---|---|
| 0 (no PE) | 61.7 | 26 | 624 | 13.0 | 0.07 | 0.14 | 0.79 |
| 1/16 | 71.2 | 30 | 720 | 19.6 | 0.8 | 0.36 | 0.56 |
| 3/16 | 68.8 | 29 | 696 | 29.3 | 0.19 | 0.45 | 0.36 |
| 7/16 | 42.7 | 18 | 432 | 33.1 | 0.43 | 0.36 | 0.21 |
| 1 | 28.5 | 12 | 288 | 36.3 | 0.64 | 0.22 | 0.14 |







Heat Load Calculations


Tens of kg quantities of Plutonium plates required for TEX configurations produce lots of heat


| Isotope | Mass per ZPPR Plate (g) | Specific Power (mW/g) ¹⁴ | Heat Source (mW) |
|-------------------|----------------------------|-------------------------------------|---------------------|
| ²³⁹ Pu | 98.87 | 1.9288 | 190.700456 |
| ²⁴⁰ Pu | 4.697 | 7.0824 | 33.2660328 |
| ²⁴¹ Pu | 0.0032 | 3.412 | 0.0109184 |
| ²⁴² Pu | 0.0049 | 0.1159 | 0.00056791 |
| ²⁴¹ Am | 0.4021 | 114.2 | 45.91982 |
| Total | 103.9772 | | 269.8977951 |

 Heat load calculations were completed to ensure temperatures would not impact the polyethylene moderators (maximum long-term service life temperature of 80 °C)



Heat Load Calculations





- ANSYS 14.5.0 Finite Element Analysis Software used to model TEX configurations with PE moderation
 - Without 0.01"
 aluminum heat
 dispersal plates
 - With 0.01" aluminum heat dispersal plates ("fins")



Heat Load Results

| Experiment Modeled | HDPE Thickness (in) | Pu Layers | T _{max} Without Fins (°C) | T _{max} With Fins (°C) |
|--------------------|------------------------|-----------|---------------------------------------|---------------------------------|
| 1 | 0 | 21 | 32 | 2.6 |
| 2 | 1/16 | 17 | 52.6 | 36.3 |
| 3 | 3/16 | 12 | 44.9 | 34.6 |
| 4 | 7/16 | 8 | 39.1 | 32.7 |
| 5 | 1 | 6 | 36.6 | 31.8 |

- T_{max} without fins 52.6°C
- Maximum long-term service temperature of HDPE is approximately 80
 °C
- Fins likely not required to keep temperature below polyethylene impact temperature
- However, fins help normalize temperature over entire stack and over the five different experiments





Subcritical Experiment Operations

- Build 4 layers of assembly of ZPPR plates (24 plates per layer) with 1/16" polyethylene moderation between each layer
- Data Goals for Experiment:
 - Weight and external dimensions for 20% of the plates- for quantification of experimental uncertainties
 - Temperature measurements over the assembly- check the utility of the fins
 - Contact and 30 cm γ/n dose rates for individual plate and assembly- help with ALARA planning for critical experiment
 - γ/n doses to personnel- help with ALARA planning for critical experiment



August 2015 Subcritical TEX Experiment









Metrology Data

- Historical ZPPR Data
 - Average Plate Net Weight:

 $130.148 \pm 0.248 g$

 Dimensional measurements- no records found, but INL used go-no-go gauges for acceptance testing, 3.01", 2.00", and 0.25"




 Measured 20 plates out of population of 100, including weight and dimensional measurements with digital caliper

| | Weight | Width (in) | Length (in) | Height (in) |
|-----|---------|------------|-------------|-------------|
| Min | 129.400 | 1.985 | 2.997 | 0.111 |
| Max | 130.700 | 1.998 | 3.009 | 0.121 |
| Avg | 130.185 | 1.993 | 3.002 | 0.117 |
| Std | 0.317 | 0.004 | 0.003 | 0.002 |

Excellent agreement with historical data!



Temperature Results



| Thermocouple Location | Max Temperature (°C) |
|-----------------------|----------------------|
| Layer 1 | 35.95 |
| Layer 2 | 37.38 |
| Layer 3 | 38.53 |
| Layer 4 | 38.85 |
| Top of Assembly | 34.42 |
| Ambient | 25.58 |

- Peak of 38.85°C with ambient temperature of 25.58°C (13.27°C ΔT)
 - Good agreement with predicted peak temperature of 36.3°C with ambient temperature of 22°C (14.3°C ΔT)
- Assembly reached equilibrium temperature after approximately 7 hours
- Confirms flat temperature profile over assembly



Dose Concerns and ALARA Planning

- Detailed Time-In-Motion study completed
 - Used limited gamma/neutron (γ/n) instrument measurement data from INL ZPPR packaging operation
 - Walked through each step of operation with real operators

| | | | | 1 | | | | 1 | |
|--------------------------------------|------|----------|-----------|-----------|-----------|-----------|-----------|-----------|----------------|
| | | Whole | Gamma | Neutron | Estimated | | Gamma | Neutron | |
| | Time | Body | Dose Rate | Dose Rate | Whole | Extremity | Dose Rate | Dose Rate | Estimated |
| Task | (s) | Distance | (mrem/hr) | (mrem/hr) | Body Dose | Distance | (mrem/hr) | (mrem/hr) | Extremity Dose |
| SAVY Can 1 | 1 | | | | · | | | | · |
| Verify item number on SAVY can | 11 | 1 m | 0.72 | 0.27 | 0.003025 | 1 m | 0.72 | 0.27 | 0.003025 |
| Verify TID | 8 | 30 cm | 8 | 3 | 0.024444 | 30 cm | 8 | 3 | 0.02444444 |
| Pick up SAVY and place on cart | 10 | 30 cm | 8 | 3 | 0.030556 | Hands on | 60 | 8 | 0.18888888 |
| Move cart to assembly table | 25 | 30 cm | 8 | 3 | 0.076389 | 30 cm | 8 | 3 | 0.076388889 |
| Remove TID | 6 | 30 cm | 8 | 3 | 0.018333 | Hands on | 60 | 8 | 0.113333333 |
| Open SAVY container | 25 | 30 cm | 8 | 3 | 0.076389 | Hands on | 60 | 8 | 0.472222222 |
| Pull out tray | 10 | 30 cm | 323 | 137.8 | 1.28 | hands on | 800 | 1400 | 6.111111111 |
| Flatten plates out, serial facing up | 16 | 30 cm | 323 | 137.8 | 2.048 | hands on | 800 | 1400 | 9.77777778 |
| MC&A Verification | 360 | 30 cm | 323 | 137.8 | 46.08 | 30 cm | 230 | 137.8 | 36.78 |
| Place four plates on cart | 12 | 30 cm | 323 | 137.8 | 1.536 | hands on | 300 | 900 | 4 |
| Move cart to measuement table | 19 | 30 cm | 323 | 137.8 | 2.432 | 30 cm | 230 | 30 | 1.372222222 |
| weigh four plates | 26 | 30 cm | 323 | 137.8 | 3.328 | hands on | 300 | 900 | 8.66666666 |
| measure four plates' dimensions | 84 | 30 cm | 323 | 137.8 | 10.752 | hands on | 300 | 900 | 28 |
| Place four plates on cart | 12 | 30 cm | 323 | 137.8 | 1.536 | hands on | 300 | 900 | 4 |
| Move cart to assembly table | 19 | 30 cm | 323 | 137.8 | 2.432 | 30 cm | 323 | 137.8 | 2.432 |
| Assemble tray 1 | 44 | 30 cm | 323 | 137.8 | 5.632 | hands on | 800 | 1400 | 26.8888888 |
| Move Tray 1 to cart | 15 | 30 cm | 323 | 137.8 | 1.92 | hands on | 800 | 1400 | 9.166666667 |
| Additional time between ops | 600 | 1 m | 20.7 | 12.4 | 5.516667 | 1 m | 20.7 | 12.4 | 138.0706111 |
| Total | 1302 | | | | 84.7218 | | | | 276.1442472 |
| | | | | | | | | | |
| SAVY Can 2 | | | | | | | | | |
| Verify item number on SAVY can | 11 | 1 m | 0.72 | 0.27 | 0.003025 | 1 m | 0.72 | 0.27 | 0.003025 |
| Verify TID | 8 | 30 cm | 8 | 3 | 0.024444 | 30 cm | 8 | 3 | 0.02444444 |
| Pick up SAVY and place on cart | 10 | 30 cm | 8 | 3 | | Hands on | 60 | 8 | 0.18888888 |
| Move cart to assembly table | 25 | 30 cm | 8 | 3 | 0.076389 | 30 cm | 8 | 3 | 0.076388889 |
| Remove TID | 6 | 30 cm | 8 | 3 | 0.018333 | Hands on | 60 | 8 | 0.113333333 |
| Open SAVY container | 25 | 30 cm | 8 | 3 | 0.076389 | Hands on | 60 | 8 | 0.47222222 |
| Pull out tray | 10 | 30 cm | 323 | 137.8 | 1.28 | hands on | 800 | 1400 | 6.111111111 |

- Conservative estimation of doses for entire activity:
 - 600 mremWhole Body Dose
 - 2100 mremExtremity Dose



Results from Dosimeters

 Deployed LLNL TLD dosimeters with CR-39 neutron dosimeters to take contact and 30 cm dose measurements

Single ZZPR Plate




Contact: 721.7 mrem/hr γ

9.6 mrem/hr n

30 cm: 0.70 mrem/hr γ

0.20 mrem/hr n

Assembly



Contact: 703.2 mrem/hr γ

44.9 mrem/hr η

30 cm: 11.7 mrem/hr γ

2.2 mrem/hr η



Personnel Doses

- Operators (fissile material handers) were issued task dosimetry and finger rings
- Operators and other personnel (RCT, MC&A, etc) were issued Electronic Personal Dosimeters (EPDs)

| Dosimeter Type | γ/n Dose to All Monitored (mrem) |
|-------------------|--|
| EPD | 42.87 |
| Combo TLD | 61 |
| (Operators only) | |
| Finger Rings | 253 |
| (Operator only) | |

 Less than 100 mrem Whole Body to all participants for the entire operation









Subcritical Experiment Conclusions

- Successfully met 4 goals for the experiment:
 - Weight and external dimensions for 20% of the plates- very good agreement with historical net weight information and provided missing information regarding actual plate sizes
 - Temperature measurements over the assembly- Fins seemed to work and we have good agreement with simulated results
 - Contact and 30 cm γ/n dose rates for individual plates and assembly- more realistic dose rates will allow for more accurate ALARA planning
 - γ/n doses to personnel- Due to careful work planning, good ALARA practice, and professional fissile material handlers, doses were significantly lower than conservative estimates



Current Work for TEX

- Fabrication of experimental trays, moderators, and experimental fixturing is complete
- Experimental plan is complete and has been submitted to facility stakeholders
- Upon approval of experiment plan, the first two experiments are ready to schedule for execution in Q3/Q4 of FY2016

